



Part No.	Name of parts	Qty	Part No.	Name of parts	Qty
101	Shuttle race	1	119	Lower shaft	1
102	Shuttle race retaining ring	1	120	Lower shaft front bushing	1
102S	Race cap spring	1	121	Set screw for 120	2
103	Set screw for 101	1	122	Lower shaft cam	1
105NS	Shuttle driver shaft shuttle driver	1	123	Set screw for 122	1
106	Shuttle driver shaft bushing	1	124	Lower shaft back bushing	1
107	Set screw for 106	1	125	Set screw for 124	1
108	Shuttle driver shaft collar	1	126	Lower shaft crank	1
109	Set screw for 108	2	127	Set screw for 126	2
110	Shuttle driver shaft bevel gear	1	130	Shuttle cleaner	1
111	Set screw (A) for 110	1	133	Gear box cover	1
112	Set screw (B) for 110	1	134	Plastic packing	1
113	Lower shaft bevel gear	1	135	Set screw for 133	3
114	Set screw (A) for 113	1	176	Washer for 119	2
115	Set screw (B) for 113	1	607	Thrust collar	2
116	Shuttle hook	1	608	Set screw for 608	4
117	Bobbin case	1	609	Washer for 126	2
118	Shuttle driving spring	1			